

## PRESSURE/TORQUE CONVERSION CHART

**14HP**

Pressure in PSI	Pressure in BAR	FT. LBS.	Nm
1000	69	1245	1688
1200	83	1537	2084
1400	97	1800	2440
1600	110	2061	2794
1800	124	2312	3135
2000	138	2611	3540
2200	152	2880	3905
2400	165	3150	4271
2600	179	3418	4634
2800	193	3685	4996
3000	207	3947	5351
3200	221	4218	5719
3400	234	4488	6085
3600	248	4760	6454
3800	262	5030	6820
4000	276	5286	7167
4200	290	5568	7549
4400	303	5803	7868
4600	317	6108	8281
4800	331	6348	8607
5000	345	6646	9011
5200	359	6897	9351
5400	372	7192	9751
5600	386	7460	10114
5800	400	7705	10447
6000	414	8008	10857
6200	427	8244	11177
6400	441	8513	11542
6600	455	8792	11920
6800	469	9062	12286
7000	483	9336	12658
7200	496	9611	13031
7400	510	9885	13402
7600	524	10172	13791
7800	538	10445	14162
8000	552	10700	14507
8200	565	10995	14907
8400	579	11272	15283
8600	593	11549	15658
8800	607	11801	16000
9000	621	12092	16395
9200	634	12352	16747
9400	648	12627	17120
9600	662	12892	17479
9800	676	13177	17866
10000	689	13443	18226