

PRESSURE/TORQUE CONVERSION CHART

2HP

Pressure in PSI	<i>Pressure in BAR</i>	FT. LBS.	<i>Nm</i>
1000	69	162	220
1200	83	180	244
1400	97	214	290
1600	110	265	359
1800	124	299	405
2000	138	335	454
2200	152	369	500
2400	165	401	544
2600	179	436	591
2800	193	471	639
3000	207	505	685
3200	221	539	731
3400	234	574	778
3600	248	610	827
3800	262	643	872
4000	276	678	919
4200	290	712	965
4400	303	747	1013
4600	317	782	1060
4800	331	817	1108
5000	345	852	1155
5200	359	886	1201
5400	372	920	1247
5600	386	955	1295
5800	400	991	1344
6000	414	1025	1390
6200	427	1058	1434
6400	441	1094	1483
6600	455	1130	1532
6800	469	1164	1578
7000	483	1197	1623
7200	496	1234	1673
7400	510	1268	1719
7600	524	1303	1767
7800	538	1337	1813
8000	552	1374	1863
8200	565	1406	1906
8400	579	1441	1954
8600	593	1475	2000
8800	607	1510	2047
9000	621	1546	2096
9200	634	1581	2144
9400	648	1615	2190
9600	662	1651	2238
9800	676	1685	2285
10000	689	1714	2324