

PRESSURE/TORQUE CONVERSION CHART

1MD

Pressure in PSI	<i>Pressure in BAR</i>	FT. LBS.	<i>Nm</i>
1000	69	125	169
1200	83	139	188
1400	97	177	240
1600	110	204	277
1800	124	228	309
2000	138	257	348
2200	152	286	388
2400	165	312	423
2600	179	341	462
2800	193	367	498
3000	207	392	531
3200	221	419	568
3400	234	445	603
3600	248	473	641
3800	262	502	681
4000	276	527	715
4200	290	554	751
4400	303	582	789
4600	317	610	827
4800	331	636	862
5000	345	663	899
5200	359	691	937
5400	372	716	971
5600	386	744	1009
5800	400	771	1045
6000	414	795	1078
6200	427	822	1114
6400	441	849	1151
6600	455	876	1188
6800	469	904	1226
7000	483	927	1257
7200	496	954	1293
7400	510	980	1329
7600	524	1007	1365
7800	538	1031	1398
8000	552	1059	1436
8200	565	1084	1470
8400	579	1109	1504
8600	593	1136	1540
8800	607	1161	1574
9000	621	1186	1608
9200	634	1212	1643
9400	648	1238	1679
9600	662	1263	1712
9800	676	1289	1748
10000	689	1318	1787